


# BRIA IPAD CONFIGURATION


### Figure 1: Home Screen

Step 1: click on the the "wrench" icon on the top right corner of the screen to go to the accounts and settings screen. (circled in orange)




# Figure 2: Accounts and Settings Screen

Step 2: click on the the "plus" icon on the top right corner of the screen to add a new SIP Softphone account. (circled in orange)



### Figure 3: Select VoIP Provider Screen

Step 3: click on the the "SIP" icon to configure settings for your softphone. (circled in orange)




### Figure 4: New SIP Account Screen

#### Step 4:

Enter the information provided by PressONE to configure your individual accounts.


#### Step 5:

Once the information has been inputted into the New SIP Account Screen, tap Account Advanced (circled in orange)



# Figure 5: Account Advanced Screen

Step 6: Fill out the Out Proxy and Authname fields with the information that was provided to you



#### Figure 6: New SIP Account Screen

Step 7: Enter VM Number: \*86

Step 8: Tap the Enabled Slider and then the large green "Register"

